

- 1. THE CONTRACTOR SHALL MAKE A 1/2" HOLE INTO THE METAL POLE FOR ELECTRICAL WIRING ACCESS. AND SHALL CLEAN THE AFFECTED AREA WITH METAL WIRE BRUSH AND PAINT WITH INORGANIC ZINC.
- 2. PUSH BUTTON ASSEMBLY SHALL BE SECURED TO WOOD POLES WITH 21/2" LAG BOLTS.

